

### New Features

Effective March 25th, 2021, Dealer Admin was updated to Version 2.60.2.

#### Unlock On REX

In Dealer Admin, you can now disable door unlock with a Request to Exit event on an X1 or X1-8 system.

When the **Request To Exit** toggle is switched on in Dealer Admin, the **Unlock On REX** toggle appears and defaults to switched on.

With this new feature you can choose what you want the Request to Exit to do.

- To allow the door to unlock when a Request to Exit input is received, switch on the **Unlock On REX** toggle. This is typically for magnetic locks. Switched on is the default.
- To keep the door locked when a Request to Exit input is received, switch off the toggle. This is typically for door strikes.

