

# INSTALLATION NOTE

## SCS-1R Printer Terminator Plug

**Note:** UL central station applications must use a serial printer listed for Fire Protective Signaling Applications.

When installing an SCS-1R without a printer, use a Printer Terminator Plug to avoid receiving the following print error message.

Activity Log Error - See Operations Manual.

1. There are two DB-25 pin connectors on the SCS-1R rear convenience panel.
2. Firmly press the printer terminator plug into the ACTIVITY LOG DB-25 pin connector.




Figure 1: DB-25 pin connectors on SCS-1R convenience panel