IOS, ANDROID & INTEGRATIONS

- Locate Virtual Keypad in the Apple or Android App Stores
- 2. Download Virtual Keypad
- 3. Locate Virtual Keypad on Apple Watch, Apple TV, and Amazon Echo
- 4. Identify the differences and capabilities of Virtual Keypad integrations

ADDING AN APP USER

- 1. Log in to Dealer Admin
- 2. Find a customer
- 3. Select APP USERS
- 4. Enter an e-mail address
- Add the appropriate AUTHORITY LEVEL and SYSTEM ACCESS

LOGGING IN

- Log in to Virtual Keypad by entering in your e-mail address and password
- 2. Check the "Terms & Conditions" check box
- 3. Enter in your USER CODE
- 4. Select SAVE USER CODE

ARMING SCREEN

- Arm and disarm the system using the ARMING section
- 2. Fault a zone at the panel and bypass it from Virtual Keypad
- 3. Select **ZONE STATUS** to see the status of all zones
- 4. Scroll to view history in the HISTORY section
- 5. Select the **EDIT** icon in the top left corner
- 6. Add CAMERAS, FAVORITES, LIGHTS, DOORS, OR THERMOSTATS to the home screen
- Add a COVER PHOTO to the top of the home screen
- 8. **REORDER** items on the home screen to customize it

CAMERAS

- 1. Add a camera or two in Dealer Admin
- 2. Select CAMERAS in the side menu
- 3. Select a camera to view a live stream
- 4. Select record to **RECORD** a clip
- 5. Select CLIPS to view recorded clips
- 6. Edit settings for a camera

HISTORY

- Ensure PUSH NOTIFICATIONS has been enabled in the SETTINGS menu
- 2. Select HISTORY in the side menu
- 3. Search for an event (Arm, Disarm, Alarm, etc)
 - Virtual Keypad will not display any history events until the panel has generated events

DOORS

- 1. Select **DOORS** in the side menu
- 2. Select the EDIT icon in the top left corner
- 3. ADD, EDIT, DELETE and REORDER Z-Wave locks
- 4. LOCK, UNLOCK, LOCKDOWN and GRANT ACCESS to an access control door

THERMOSTATS

- 1. Select THERMOSTATS in the side menu
- 2. Select the EDIT icon in the top left corner
- 3. ADD, EDIT, DELETE and REORDER Z-Wave thermostats

LIGHTS

- 1. Select LIGHTS in the side menu
- 2. Select the EDIT icon in the top left corner
- ADD, EDIT, DELETE and REORDER Z-Wave thermostats

FAVORITES

- 1. Select **FAVORITES** in the side menu
- 2. Select the **EDIT** icon in the top left corner
- 3. ADD, EDIT, DELETE and REORDER Z-Wave favorites

USERS

- 1. Select **USERS** in the side menu
- 2. Select the EDIT icon in the top left corner
- 3. Select ADD to add a user
- Enter a USER NAME and configure settings for this user
- 5. Create an **APP USER** for this user by entering an e-mail address
- 6. Select SAVE to save this user
- 7. Select the **EDIT** icon in the top left corner
- 8. EDIT and DELETE a user

SCHEDULES

- 1. Select **SCHEDULES** in the side menu
- 2. Select the EDIT icon in the top left corner
- 3. Select ADD to add a schedule
- 4. Select the type of schedule to add
- 5. Select the PLUS icon next to times
- 6. Select the frequency
- 7. Enter the **BEGIN** and **END** time
- 8. Select **SAVE** to save this schedule
- 9. EDIT and DELETE a schedule

PROFILES XR ONLY

- 1. Select **PROFILES** in the side menu
- 2. Select the **EDIT** icon in the top left corner
- 3. Select ADD to add a profile
- 4. Configure the profile's permissions
- 5. EDIT and DELETE a profile
- 6. Apply the profile to a user in the USER menu

REFER A FRIEND

- 1. Select **REFER A FRIEND** in the side menu
- 2. Customer can receive a special offer for referrals

ACTIONS

- 1. Select **ACTIONS** in the side menu
- 2. Select a system event
- 3. Select the favorite you want to activate
- 4. Select the **BACK** arrow to save the action
- 5. To delete an action, select a system event and select **NONE**

TRAFFIC COUNT

- Ensure TRAFFIC COUNT is turned on in the PUSH NOTIFICATIONS menu
 - The system will need to be armed to send a traffic count report
- 2. Select TRAFFIC COUNT in the side menu
- 3. View the traffic count data for a programmed zone

SETTINGS

- 1. Select **SETTINGS** in the side menu
- 2. Select **TODAY WIDGET** to customize widgets
 - ▶ iOS only
- Select PUSH NOTIFICATIONS to customize notifications and SENSOR ACTIVITY
- 4. Select **CHIME** to customize the chime sound per zone
- 5. Select LOGOUT to log out of Virtual Keypad
- 6. Select **DEFAULT SYSTEM** to choose the default system when launching Virtual Keypad
- 7. Select **SYSTEMS** in the side menu to view additional systems this app user has access to

QUESTIONS

What else would you like to learn about Virtual Keypad?

- Custom Actions
- Video Actions
- Notifications

CHECK LIST

	App Downloaded
	User Name and Password
	User Code
	Home Screen Customized
	Push Notifications Turned Or
	Widgets Added
	Refer A Friend

N	0	Г		C	
N	$\mathbf{\mathcal{C}}$		_	-	

•••	• •	• •	• • •	 • •	 • •	٠.	•	 • •		•	 •			•	 •		•				 •			 •				 	 	•
•••				 	 	٠.		 ٠.					 						 	 								 	 	
				 	 	٠.		 ٠.					 						 	 							 	 	 	•
		• •		 	 			 																				 		
				 • •	 			 					 															 		
				 	 			 								• •												 	 	
				 	 			 ٠.			 •		 	•			 •		 									 		
				 	 	٠.		 			 •		 	•			 •		 									 		