

# XTLN/XTLN-WIFI FAST PROGRAMMING SHEET

Name \_\_\_\_\_ Account Number \_\_\_\_\_ Date \_\_\_\_\_

Address \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

**Communication**

Account Number    \_ \_ \_ \_ \_    (1 to 65,535  
  default = **12345**)

First IP Address    \_ . \_ . \_ . \_

**Remote Options**

APP Key            \_ \_ \_ \_ \_

**System Options**

System            AREA   **A/P**    H/S/A  
Hours from GMT    \_ \_   (0 to 23 hrs., default = **6**)  
Weather Zip Code   \_ \_ \_ \_ \_    Default = **0**

**Output Setup**

**Output 41            ALARM SOUNDER 1**

Serial #            \_ \_ \_ \_ \_

**Note:** Bell Output automatically set to Output 41.

**Zone Information**

Zone #	Zone Name	Zone Type	Area	Serial Number
1	FRONT DOOR	EX	PERIM	
2	BACK DOOR	EX	PERIM	
3	INTERIOR DOOR	NT	INT	
4	UPSTAIRS DOOR	EX	PERIM	
5	BASEMENT DOOR	EX	PERIM	
6	GARAGE DOOR	EX	PERIM	
7	WAREHOUSE DOOR	EX	PERIM	
8	SHIPPING DOOR	EX	PERIM	
9	BREAKROOM DOOR	NT	INT	
10	STOCKROOM DOOR	NT	INT	
11	FRONT MOTION	NT	INT	
12	BACK MOTION	NT	INT	
13	INTERIOR MOTION	NT	INT	
14	UPSTAIRS MOTION	NT	INT	
15	BASEMENT MOTION	NT	INT	
16	GARAGE MOTION	NT	INT	
17	GLASS BREAK	NT	INT	
18	WATER DETECTOR	AUX 1	INT	
19	LOW TEMPERATURE	AUX 1	INT	
20	SMOKE DETECTOR	FI		
21	FRONT SMOKE	FI		
22	BACK SMOKE	FI		
23	INTERIOR SMOKE	FI		
24	UPSTAIRS SMOKE	FI		
25	BASEMENT SMOKE	FI		
26	GARAGE SMOKE	FI		
27	WAREHOUSE SMOKE	FI		
28	SHIPPING SMOKE	FI		

